

---

## HM Nabavian Stair Rod Overview/Installation guide

*Stair rods are for decorative use and not intended to be the primary method of securing and holding down your carpet runner. Make sure your carpet runner is properly installed before installing stair rods.*

- ❖ Attach finials to brackets with provided screws. If you did not purchase finials, skip this step.
- ❖ Locate the desired position of your brackets (preferably centered with equal distance on either end of your steps. Make sure the final position you select will fit your rod's length. We recommend a minimum of 1.5" of space on either side of your runner and bracket.
- ❖ Once your bracket location is determined, you can begin installing brackets. Slide open the latch on the brackets to reveal the holes where the installation screws will go.
- ❖ Note: Provided screws are meant for use on wood stairs. If your stairs are a different material, we suggest using appropriate anchors.
  - ❖ Drill pilot holes
  - ❖ Insert provided screws
  - ❖ Insert rod and locate exact position of the next bracket
  - ❖ Install second bracket

Call/Email us with any questions

info@hmnabavian.com

(800) 352-7510

hmnabavian.com